

# HUSQVARNA VIKING® H|CLASS™ E10

## Master the Basics

- All-Purpose Foot
- Blind Hem Foot
- Zipper Foot
- Buttonhole Foot
- Satin Stitch Foot

### HUSQVARNA VIKING® H|CLASS™ E10 Features

- 21 Decorative and Utility Stitches
- 5 Accessory Feet
- Built-in needle threader
- Easy Stitch Selection



| Feature   | Technique   | Talk About   |
|---|---|--|
| <p><b>Sews All Fabric Types</b></p>  <p><b>(kite-tail – jeans hem)</b></p> | <p>FABRIC: Medium Woven, Tricot<br/>           SELECT: Stitch Selector “A”, Stitch Length 2.5<br/>           USE: All-Purpose Foot<br/>           SEW: Fold medium woven and tricot in half. Sew along the fold at 5/8” seam allowance.</p> <p>FABRIC: Denim<br/>           SELECT: Stitch Length 3.0<br/>           SEW:</p> <ul style="list-style-type: none"> <li>• Fold denim in half (wrong sides together).</li> <li>• Sew with fold at 5/8” seam allowance.</li> <li>• Fold seam to one side.</li> <li>• Topstitch down in place.</li> <li>• Fold up raw edge twice to form hem.</li> <li>• Sew hem in place.</li> </ul> | <ul style="list-style-type: none"> <li>• The HUSQVARNA VIKING® HICLASS™ E10 sewing machine will sew all different types of fabrics, without having to change the tensions.</li> <li>• HUSQVARNA VIKING® HICLASS™ E10 sewing machine will handle any of your heavy-duty projects such as hemming jeans, home dec, or craft sewing with specialty fabrics.</li> <li>• Electronic power provides a greater penetration even at slower speeds, whether stitching one stitch at a time or at full speed.</li> </ul> |
| <p><b>Easy Threading and Bobbin Winding</b></p>                          | <ul style="list-style-type: none"> <li>• Show threading the top thread.</li> <li>• Show where the bobbin is wound and point out the automatic bobbin stop.</li> <li>• Show how easy it is to load the bobbin from the front of the machine.</li> </ul>  | <ul style="list-style-type: none"> <li>• The HUSQVARNA VIKING® HICLASS™ E10 sewing machine has an easy threading system. Watch how quickly you can thread it.</li> <li>• Notice the handy thread cutter on the side.</li> <li>• The bobbin winder automatically disengages the needle for easy bobbin winding.</li> <li>• The automatic bobbin stop prevents overwinding.</li> <li>• A handy needle and thread information chart is included in the User’s Guide.</li> </ul>                                   |
| <p><b>Worry – Free Tension</b></p>  | <ul style="list-style-type: none"> <li>• Show the tension dial.</li> <li>• Show how the normal range is indicated on the tension dial with a line between 3 and 5.</li> </ul>   | <ul style="list-style-type: none"> <li>• For many types of fabrics, tension adjustment is not needed on the HUSQVARNA VIKING® HICLASS™ E10 sewing machine.</li> </ul>  |

## Feature

## Technique

## Talk About

|  |  |   |
|--|--|---|
| <p><b>Perfect Repeating Buttonholes</b></p>                 | <p>FABRIC: Medium woven with stabilizer (bullet and indent) Fold fabric in half with stabilizer between layers (next bullet) Mark the buttonhole position on the fabric</p> <p>SELECT: Buttonhole Stitch 1, stitch length - Buttonhole setting</p> <p>USE: Buttonhole Foot</p> <p>SEW:</p> <ul style="list-style-type: none"> <li>• Snap on the Buttonhole Foot.</li> <li>• Pull the Buttonhole Foot forward as far as it will go.</li> <li>• When lowering the Buttonhole Foot, position the fabric so that the needle is on the mark that is furthest from you.</li> <li>• To begin sewing the buttonhole, turn the stitch selection dial so that the picture of the buttonhole with a "1" next to it appears in the stitch display window.</li> <li>• Set the stitch length dial to the buttonhole setting.</li> <li>• The HUSQVARNA VIKING® HICLASS™ E10 sewing machine will sew toward you, forming the right side of the buttonhole.</li> <li>• Sew at a moderate speed until you reach the marking on the fabric indicating the bottom of the buttonhole.</li> <li>• Turn the Stitch Selection dial so the picture of buttonhole with a "2" and a "4" appears in the stitch display window.</li> <li>• As you begin sewing again, the HUSQVARNA VIKING® HICLASS™ E10 sewing machine will sew the lower bartack. Sew just a few stitches to form the bartack.</li> <li>• Turn the Stitch Selection dial to the picture of a buttonhole with a "3" next to it and sew the left side of the buttonhole. Stop sewing at the mark at the end which is furthest from you.</li> <li>• Turn the Stitch Selection dial back to the picture of the buttonhole and a "2" and "4" next to it. Sew a few stitches to form the top bar tack.</li> </ul> | <ul style="list-style-type: none"> <li>• The buttonhole is repeated easily by using the marked lines on the foot as a guide. This is great when you are sewing many buttonholes of the same length. <b>Show a buttonhole sample.</b></li> </ul> |
| <p><b>Seam/Overcast Stitches (Simulated Serging)</b></p>  | <p>FABRIC: Sweatshirt fleece and ribbing</p> <p>SELECT: "G" on Stitch Selection dial, stitch length "S1"</p> <p>USE: Satin Stitch Foot</p> <p>SEW:</p> <ul style="list-style-type: none"> <li>• Fold sweatshirt fleece in half and cut a small curve.</li> <li>• Fold ribbing in half lengthwise, stretch and sew on as a neckline.</li> </ul>   | <ul style="list-style-type: none"> <li>• Sew the Seam/Overcast the edge at the same time. The Seam Overcast stitch prevents raveling of the seam allowance on a woven fabric and creates a seam that will stretch on knit fabrics.</li> </ul>   |

| Feature  | Technique   | Talk About  |
|--|---|---|
| <p><b>Easy Blind Hem</b></p>    | <p>FABRIC: Wool<br/> SELECT: "F" on Stitch Selection dial<br/> USE: Blind Hem Foot<br/> SEW:</p> <ul style="list-style-type: none"> <li>• Fold up a hem on a piece of wool.</li> <li>• Sew the hem with the fold riding along the guide of the foot, just catching the fold with the left swing of the needle as you stitch.</li> <li>• Adjust the guide on the presser foot as needed to catch just a thread from the fold.</li> </ul> | <ul style="list-style-type: none"> <li>• You can "fine tune" the blind hem by adjusting the guide on the Blind Hem Foot for different types of fabric.</li> </ul>   |
| <p><b>Needle Positions</b></p>  | <ul style="list-style-type: none"> <li>• Snap on the All-Purpose Foot.</li> <li>• Use a piece of medium weight woven fabric.</li> <li>• Select the straight stitch with the right needle position "B". Sew a row of stitching.</li> <li>• Select the straight stitch with center needle position "A".</li> <li>• Sew another row of stitching next to the first row.</li> </ul>   | <ul style="list-style-type: none"> <li>• Topstitching, understitching and edge stitching are made much easier with this feature. Perfect for garment sewing.</li> </ul>   |
| <p><b>Jam Proof Bobbin</b></p>   | <ul style="list-style-type: none"> <li>• If this feature is important to the customer, demonstrate a HUSQVARNA VIKING® EMERALD™ I83 or higher sewing machine.</li> </ul>  |   |
| <p><b>Easy Stitch Selection Built-In Decorative Stitches</b></p>   | <p>FABRIC: Medium woven and stabilizer<br/> SELECT: "D" on Stitch Selection dial, "S1" on stitch length dial<br/> USE: All-Purpose Foot<br/> SEW: Selected decorative stitch</p>  | <ul style="list-style-type: none"> <li>• Just dial a stitch and you are ready to sew.</li> <li>• Decorative stitches are a great way to add interest to a project or even embellish a readytowear garment.</li> </ul> <p>Show a sample using decorative stitches.</p> |
| <p><b>Alphabets/ Monograms</b></p>   | <p>If this feature is important for the customer, demonstrate a HUSQVARNA VIKING® EMERALD™ I83 or higher sewing machine.</p>  | <ul style="list-style-type: none"> <li>• Show sample of lettering.</li> </ul>   |
| <p><b>Machine Setting Advice</b></p>   | <p>If this feature is important for the customer, demonstrate a HUSQVARNA VIKING® EMERALD™ I83 or higher sewing machine.</p>  |   |
| <p><b>Quilting Features</b></p>  | <p>If this feature is important for the customer, demonstrate a HUSQVARNA VIKING® EMERALD™ I83 or higher sewing machine.</p>  | <ul style="list-style-type: none"> <li>• Show samples of quilting stitches.</li> </ul>  |